SmartPad® neo

ENGLISH

User Manual

Congratulations for buying SmartPad EP752 NEO!
Thank you very much for your trust and your decision to buy an EASYPIX product!

As we constantly update and improve SmartPad there may be small differences between the printed manual and your SmartPad in some cases. You have the option of downloading the current version of the manual and firmware updates for your SmartPad from our website www.easypix.eu.

SmartPad® for Android™

easypix® free & easy

Table of Contents

Safety instructions 3
Device overview 4
Description of the buttons 5
Language settings 6
Power monitoring
and charging the batteries 7
Screen lock 7
Connecting with computer and data transfer 7
Functions of the buttons on the
user interface 8
Programme menu 9
System settings 11
WiFi 11
Sound 13
Display 13
Storage 13
Apps 13
Accounts & sync 13
Location services 14
Security 14
Language & input 14
Backup & reset 14
Date & time 14
About tablet 14
Internet 15
Open Source Code & GNU General Public License 17
Technical Data 18

This user manual contains important safety instructions and information for proper use of the device. Please follow the instructions in this manual carefully.

A Please keep the device away from places with high temperatures, high humidity or dust.

B In particular please avoid leaving the device in the car during summer if the doors are closed.

C Avoid shocks and do not let the device fall, as otherwise it may cause damage to the device.

D The Standby Time of the batteries may vary due to different environmental influences.

E We are not responsible for data losses that are caused by damage to the product, repairs or any other reasons.

F Do not open the housing of the device. Doing this will void your warranty claims.

G Do not use alcohol, thinners or petrol to clean the display – use only a dry cloth.

Device overview

1. Camera
2. Power button
3. Earphone
4. USB Port
5. DC-in
6. Volume
7. Micro SD Card Slot
8. Reset

Description of the buttons

Volume Buttons:
Here you can increase or reduce the volume.

Power Button:
Press the button for two seconds to switch on or switch off the device. Press the button briefly to activate or end the Standby-Mode. Reset: Press the button for seven seconds to restart the device.

ESC Button:
To go back to the previous menu

Menu Button:
To open the context menu

Home Button:
To go back to the user interface

Language setting

SmartPad EP752 NEO is delivered with English as a default language.
To change the language setting, please do the following:

- Press on the programme menu symbol  on the right side of the screen

- Select 'Settings' 

- Scroll to the end of the list
- Select 'Language & input'
- Select 'Language'
- Type your preferred language
- Press the 'Home' button to return to the home screen

Power monitoring and charging the batteries

The battery charge symbol in on the status bar indicates the charging status of the batteries.
If the power goes down, the device shuts itself off automatically.
If less power is shown, use the power adapter
to charge the device.
The charging time for the battery is approximately four hours.

Screen lock

If the device is not used for specified time or the 'Power' button is pressed briefly, the screen is switched off and display lock is activated.
By pressing the 'Power' button briefly the screen will be reactivated.
For locking the screen press the 'Lock' button in the specified direction.

Connecting to the computer and data transfer

SmartPad is equipped with a High-Speed USB2.0 Interface.
After you connect the device to a computer, it appears in the status display

Functions of the buttons on the user interface:

Home Button:
To go back to the start screen.

Menu Button:
To open the context menu (not in all apps available).

Back Button:
To go back to the previous menu / previous page.

 Program Menu Button:
To display the programs and applications.

WI-FI Signal Icon

System instruction (example)

Program menu

ApkInstaller:
Program for installing and uninstalling Apps that were not downloaded from the Android Market.

Market / Play Store:
Load Apps (programs) from the Android Market. You can download and install apps, games and other applications. Many are free.

Explorer:
Open the Explorer to access Micro SD TF Cards, USB sticks and other storage media. The Explorer is a practical manager for documents and all types of data.

Internet browser

0.3MP camera

E-mail:
Program for retrieving, processing and sending e-mails.

Google Mail:
Program for retrieving, processing and sending e-mails through Google account.

Google Maps:
Program for the display of maps or satellite images – route planner.

Calendar:
Managing schedules – can be synchronised automatically with a Google account.

Pocket Calculator

Time:
Time display and setting alarm functions.

Settings:
Changing the basic settings of SmartPads.

Sound Recorder:
Dictation Device Function.

Video Player

Gallery:
Manage and display images and videos – also enables synchronisation with Picasa web albums.

E-Book:
A program for reading and managing e-books.

System settings

Touch the icon for the settings

to open the system settings menu:

Wi-Fi

Touch ‘Wi-Fi’.



WI-FI: Touch 

=> 

to switch on the WI-FI function.

The device automatically searches for available WI-FI networks.

WI-FI Settings: Select your network here.
If needed you will be requested to enter your WI-FI password:



Advanced Wi-Fi settings:

Touch in the menu for Wi-Fi Settings, the menu for advanced settings will open up automatically. In the menu for the advanced settings you can view the current status, the IP address and other device information.

Sound
The 'Sound' settings contain the volume control, and selection of notification sounds, system sounds, signal tones for Micro SD/TF Cards and USB signal tone.

Display
Includes brightness, automatic screen rotation (G-sensor), animations and display timeout time, Switch off display after : 15 seconds, 30 seconds, 1 minute, 2 minutes, 10 minutes or 30 minutes are available. For example, if you select 30 seconds, the display will be switched after 30 seconds of inactivity and screen lock is activated. Press the 'Power' button to reactivate the Display. Push the 'Lock' button up to lift the screen lock.

Storage
Here the current memory use is displayed.
Touch 'Remove SD Card' to remove the Micro SD/TF Card during use.

Apps
Here you can manage your apps and define if apps from sources other than the Android Market are allowed to be installed.

Accounts & sync
General synchronisation settings:
1. Background data
2. Automatic synchronisation

Account management: Management of user accounts

Location services
Here you can activate the automatic recognition of the location.

Security
You can also set security passwords which will prevent unauthorised access to your SmartPad.

Language & input
Set the system language and input method.

Backup & reset
Secure my data: Here you can define if different settings should be stored on Google servers.

Touch 'Reset to default' to reset the device to factory settings. All settings, self-installed apps and data stored on internal memory can be deleted.

Date & time
If your network does not support automatic setting of time, you can set the time, time zone and date manually after deactivating automatic settings.

About tablet
Here you can view device internal values such as operating system version, battery status, signal strength of the mobile network etc.

Main functions

Internet

Touch

Icon to surf the net.
Easypix.eu is the default start page.
Touch the input field to display the keyboard.

Touch after entering a website address to open the website.

Note: The Android keyboard has few options for settings such as: keyboard language, numbers and icons etc.

The Internet browser can open four websites simultaneously.

Touch and the menu will be displayed as follows:



Open Source Code:

http://www.easypix.info/download/smartpad_neo/open_source.zip

GNU General Public License:

http://www.gnu.org/licenses/gpl-2.0.html

For technical help please visit our support area on www.easypix.eu.

Technical Data

SmartPad EP752 NEO	7" / 17.7cm tablet PC
CPU	RK2926 1.2GHz with Mali 400 GPU
Operating System	Android 4.1
RAM	512MB DDR3
Internal Memory	4GB NAND Flash
Memory Expansion	Micro SD cards up to 32GB
Display	16:9 Capacitive 5-point Multi-Touch-Display
Resolution	800 x 480 Pixel
G-SENSOR	Yes
Camera	0.3MP
Battery	2500mAh 3.7V rechargeable Li-ion Battery
	5V/2A DC-In
WIFI	802.11b/g/n
I/O ports	1x DC In, 1x headphone, 1x Card-Slot,
	1x USB 2.0

rk29sdk_gpl_kernel_20110702
Copyright © Rockchips

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License, version 2, as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License, version 2, for more details.

You should have received a copy of the GNU General Public License, version 2, along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110, USA

You should receive a complete machine-readable copy of the corresponding source code of this program under the following
link: http://www.easypix.eu/download_easypad.html
if not, write to Easypix, Corinne Loose, Em Parkveedel 11, D-50733 Cologne, Germany, e-mail: support@easypix.eu

Easypix herebly declares that the product SmartPad EP752 NEO is in conformity to all the essential requirements of Directive 1999/5/EC.
The declaration of conformity can be downloaded here:
http://www.easypix.info/download/smartpad_neo/konformitaetserklaerung/

Easypix herebly declares that the product battery charger for the SmartPad EP752 NEO is in conformity to all the essential requirements of Directive 1999/5/EC.
The declaration of conformity can be downloaded here:
http://www.easypix.info/download/smartpad_neo/konformitaetserklaerung/